

## MASONRY

### PLASTERBOARD (Wooden carpentry)

The channels are placed fixed to the floor, to the ceiling, and to the door lintel, before marking. After that, the studs are placed into the channels. These channels are made of galvanized steel sheet.

The door frame is fixed to the studs through auxiliaries screwed sheets.

The plasterboard panels are screwed to the auxiliary frame through self-drilling screws.

The tubes and boxes for electric mechanisms are placed now and after this, we place the fill in with fiber-glass like thermo-acoustic insulation.

The face panels are screwed and the partition has been painted.

Finally the flashing has been screwed to the door frame and the skirting has been screwed to the partition.