

MASONRY

PLASTER PLAQUE PARTITION (Wooden subframe)

The wooden subframe is placed. Then a polystyrene expanded sheet is placed in the lower part of it, to reduce the possible difference in floor level.

The tongue and groove joint plaster plaques are jointed among them with plaster paste.

In these type of partitions, the pieces which will be placed are plotted, from the top of the subframe to the floor, you should cut (if it's necessary) the pieces of the lower row, to get that this first row would be supported on the edge (it will be flat).

From the top of the subframe to the ceiling, all the pieces will be whole pieces, without cuts, to facilitate the joint among the plaster plaques.

The subframe is fixed to the partition through crossed nails. The partition has laid a plaster paste as cladding.